

Multi-element piezo-composite transducers for structural health monitoring

Erling Ringgaard, Tomasz Zawada CTS | Ferroperm, Kvistgaard, Denmark

Thomas Porchez, Nabil Bencheikh, Ronan Le Letty Cedrat Technologies SA, 15 Chemin de Malacher, Meylan, 38246, France

Piezo 2011, 2_{nd} March 2011, Sestriere, Italy







Outline

- Short company presentation
- Introduction to structural health monitoring and the AISHA II project
- Lamb waves and array transducers
- Development of piezo-composites
- FEM modelling
- Integration and testing of array transducers
- Conclusions and outlook



Structural health monitoring

Structural health monitoring

- A collective term for advanced technologies using sensor networks for monitoring of structures of high importance
 - Bridges
 - Buildings
 - Aircraft
- For aircraft, SHM is closely linked to the Maintenance, Repair and Overhaul schedule
 - Light maintenance (A-check, duration < 24 h, interval 2 months)</p>
 - Base maintenance (C- and D-checks, duration 1 5 weeks, interval 2 10 years)
- Main benefits of SHM:
 - Cost savings by reduction of inspection costs and possible weight reduction in the design phase
 - Enhancement of safety by more frequently applied automated inspections
 - Increase of passenger throughput by reduction of maintenance time and by better maintenance planning

AISHA II project

- Aircraft Integrated Structural Health Assessment II
- FP7 Theme TRANSPORT (incl. AERONAUTICS)
- 5 full-scale parts selected as cases for SHM:
 - fatigue cracks in slat tracks of Airbus A320 and A380
 - impact damage in the tail boom of the helicopter Eurocopter EC135
 - fatigue cracks in the helicopter tail boom of a MIL Mi-8
 - corrosion in floor beams of Airbus A340
 - fatigue damage in doubler repairs of Airbus A340
- Focus on hot spots
- Examples of sensing technologies:
 - piezoceramic transducers for ultrasonic Lamb waves
 - EMAT sensors for ultrasonic Lamb waves
 - electrochemical sensors
 - optical fibre sensors

AISHA II full-scale parts













AISHA II consortium

- Katholieke Universiteit Leuven, MTM & ATF (BE)
- METALOGIC nv (BE)
- Deutsches Zentrum f
 ür Luft- und Raumfahrt, DLR (DE)
- CEDRAT Technologies SA (FR)
- EUROCOPTER Marseille (FR)
- Riga Technical University (LV)
- CENTRO DE TECNOLOGIAS AERONAUTICAS, CTA (ES)
- ASCO Industries nv (BE)
- Fraunhofer Institute for Manufacturing Technology and Applied Materials Research, IFAM (DE)
- Universität Leipzig (DE)
- LUFTHANSA Technik (DE)
- Vrije Universiteit Brussel (BE)
- University of the Basque Country (ES)



Lamb waves

Lamb waves

- A type of guided waves also known as plate waves
- For frequencies in the range of a few hundred kilohertz, only the lower-order Lamb waves, S_0 and A_0 , will be significant
- r S₀ and A₀ are called the symmetric and antisymmetric modes, respectively
- r S_0 is the fastest of the two and the one most sensitive to defects





Lamb waves for SHM

- The main challenge in using Lamb waves for SHM is the multitude of interfering echoes leading to a heavy burden of signal processing
- A convenient solution is to apply mode and direction selectivity by means of a linear array piezoelectric transducer
- In the linear array, the elements are separated by a fixed pitch
- By simple signal processing, waves propagating at different velocities can be distinguished
 - Undesired waves are filtered out by virtually creating destructive interference
 - The interesting wave is amplified by virtually creating constructive interference
- Mode selection delay:

 $t_{delay} = pitch/velocity$



Piezo-composite transducers

2-2 composites as linear arrays

- Composite transducers have very interesting acoustic properties (damping of transverse modes, possibility of electronic scanning, focusing and beam steering)
- 2-2 composites have a multilayer structure (2D connectivity for both the ceramic (active) phase and the polymer (passive) phase)
- Ferroperm soft PZT (Type 100) has been chosen as the piezoceramic



Characterisation of 2-2 composites, 1st generation

Impedance spectrum shows difference seen between inner and outer elements





FEM modelling

FEM modelling of 2-2 composite

 An FEM model has been set up in COMSOL Multiphysics in order to investigate the uniformity of response over the piezoceramic elements

N

- Dimensions of composite part:
 - piezoceramic: 8 elements of L 30 mm * W 0.55 mm * h 3 mm
 - polymer: 7 elements of W 0.55 mm
 - wrap-around electrode not considered
- Model definition and input data (preliminary):
 - piezoceramic: standard soft PZT
 - polymer: density 930 kg/m³, elastic modulus 1 GPa, Poisson ratio 0.33
 - the part is fixed on the bottom side (~ glue with ideal clamping)
 - rectangular meshing used (34 * 30 * 4 elements)





N

Static displacement

A plot of the displacement shows higher values at the ends of the element
 Similarly for outer elements (*z*-displ., end view and central cross section)



Min: -9.186e-24

2-2 composites manufactured, 2nd generation

- A different polymer was selected
- A number of improvements were made to the process
- 2nd generation devices show improved quality and uniformity



Characterisation of 2-2 composites

Impedance spectrum shows enhanced resonance



Reproducibility of 2-2 composites

Resonance very reproducible between elements





Integration and testing of array transducers



- Arrays mounted with flex PCB by soldering
- Two arrays glued to an aluminium plate
- Both arrays connected to a dedicated SHM electronics module
 - High-frequency excitation (bandwidth up to 2 MHz)
 - PULSECHO functionality (emission and reception on same piezoelectric patch)
 - 4 channels per daughter board







Mode and direction selection



Conclusions and outlook

- Ultrasonic inspection using Lamb waves is an important method for SHM
- By using arrays instead of single patches it is possible to perform mode selection in a very efficient manner
- 8-element linear arrays for SHM have been manufactured successfully in the form of 2-2 composites, obtaining a high degree of reproducibility
- Mode selection in reception of either the S₀ or A₀ mode has been demonstrated
- The selectivity of either mode can be further enhanced by combining selective emission and selective reception
- In the near future, similar 8-element arrays in the form of thick films will be tested



Acknowledgement

The research leading to these results has received funding from the European Community's Seventh Framework Programme [FP7/2007-2013] under grant agreement no. 212912:

Aircraft Integrated Structural Health Assessment II





The information contained in this document is the property of CTS | Ferroperm and is proprietary and/or copyright material. This information and this document may not be used or disclosed without the express authorization of CTS | Ferroperm. Any unauthorized use or disclosure may be unlawful.

The information contained in this document may be subject to the provisions of the trade compliance regulations (including those regulations governing transfer to a dual national or third country national, export and re-export) of various countries; see the first page for specific requirements. The recipient acknowledges that licenses from the applicable regulatory agency or agencies may be required before the recipient may further disclose such information to others, and that such licenses may impose restrictions on further disclosure of such information. The recipient agrees to comply with all applicable governmental regulations as they relate to the transfer, export and re-export of information disclosed in this document.'